Product specification sheet

Product	Router Tenda N301
SKU	router-tenda-m300
Brand	TP-Link
Category	Communication Equipment
Minimum order quantity	1
Unit	—
Unit price	$15.00
Available quantity	100

Description

Wireless Router Mode: The standard setup where you plug your ISP modem into the WAN port. Universal Repeater Mode: Extends the range of your existing Wi-Fi signal without needing a cable. WISP Mode: Connects wirelessly to an ISP hotspot (like a public park or apartment complex Wi-Fi) and shares that connection with your local devices. Access Point (AP) Mode: Connects to a primary router via Ethernet to create a new Wi-Fi broadcast point.

Generated 2026-11-05 00:55:25 · Masdar Lebanon