

Product specification sheet

Product	Dyson PencilWash Wet Cleaner
SKU	cm-WR04-A 637239-01
Brand	Dyson
Category	Consumer Electronics
Minimum order quantity	1
Unit	—
Unit price	\$399.00
Available quantity	100

Description

Dyson PencilWash Cordless Wet Cleaner The Dyson PencilWash Cordless Wet Cleaner is designed for users who want a slim, lightweight, and hygienic hard-floor cleaner for wet spills, dry dirt, stains, and quick everyday cleaning. With a 64,000-filament microfiber roller, automatic dirt extraction, eight hydration points, self-propelled motion, self-cleaning design, 30-minute run time, LED screen, two cleaning modes, and a low-profile body that leans back 170°, it is built for fast hard-floor washing with better control and easier storage.

Key Features

Slim Cordless Wet Cleaner Designed for hard-floor washing in a lightweight, narrow, and easy-to-maneuver body.

64,000 Microfiber Filaments The absorbent roller helps wash away wet spills and stains while also removing dry dust and dirt.

Wet & Dry Mess Cleaning Cleans wet spills, stains, dust, dirt, and debris at the same time on suitable hard floors.

Automatic Dirt Extraction Dirty water and debris are removed from the roller on every rotation to help keep cleaning performance consistent.

Eight Hydration Points Clean water is delivered across eight points to refresh the roller evenly from start to finish.

300ml Clean Water Tank at the Cleaner Head The clean water tank is placed near the base for better balance and control while cleaning.

Self-Propelled Motion A motorized brush bar rotates the roller, helping the cleaner glide forward with less effort.

Self-Cleaning Design Designed to clean the roller system after use for easier maintenance.

Ultra-Slim Handle The 1.5-inch diameter handle feels light in hand and steers naturally with a simple twist.

Low-Profile Cleaning Leans back up to 170° to clean under low furniture and into tighter spaces.

Flexing Neck Swivels around table legs, furniture, and obstacles for smoother movement.

LED Screen Displays power modes, battery charge, and maintenance alerts.

Two Power Modes Standard mode is made for everyday hard-floor cleaning, while MAX mode is designed for spot-cleaning stains.

Quick-Drying Finish Designed to leave floors clean and dry within minutes.

Compact Storage Includes a wand charging dock and clip-on drip tray for cleaner, space-saving storage.

Main Feature Sections

Microfiber Roller Cleaning The Dyson PencilWash uses a 64,000-filament microfiber roller to wash hard floors while picking up dust, dirt, debris, and wet spills. This makes it useful for everyday floor maintenance and quick cleaning after kitchen or household messes.

Continuous Clean Water Hydration Eight hydration points keep the roller refreshed with clean water throughout cleaning. This helps maintain even floor coverage instead of relying on one concentrated water point.

Automatic Dirt Extraction Dirty water and debris are extracted from the roller on every rotation, helping reduce the chance of spreading dirty water across the floor.

Self-Propelled Handling The motorized brush bar creates smooth self-propelled movement, making the cleaner easier to guide across hard floors with less pushing effort.

Low Furniture Cleaning The low-profile format leans back up to 170°, helping users reach under furniture and into tight spaces without losing cleaning performance.

Technical Specifications

Product Type: Cordless Wet Floor Cleaner **Brand:** Dyson **Model:** PencilWash **Cleaning Type:** Wet and dry hard-floor cleaning **Roller Type:** Microfiber roller **Microfiber Filaments:** 64,000 **Hydration Points:** 8 **Clean Water Tank Capacity:** 0.08 gallon / 300ml **Dirty Water Tank Capacity:** 0.09 gallon **Run Time:** Up to 30 minutes **Cleaning Coverage:** Up to 1,076 sqft **Battery Type:** 4-cell lithium-ion battery **Power Modes:** Standard and MAX **Display:** LED screen **Self-Propelled:** Yes **Self-Cleaning:** Yes **Low-Profile Cleaning:** Leans back up to 170° **Handle Diameter:** 1.5 inches **Weight:** 4.6 lb **In-Hand Weight:** 0.84 lb **Height:** 45.5 inches **Length:** 10.5 inches **Width:** 7.8 inches **Use Case:** Hard-floor washing, wet spills, dry dirt, stains, quick cleaning, kitchen floors, living spaces, and under-furniture cleaning **Battery Life** **Run Time:** Up to 30 minutes **Battery:** 4-cell lithium-ion battery Actual run time may vary depending on cleaning mode, floor type, stain level, movement speed, and maintenance condition.

Cleaning Modes **Standard Mode:** Default mode for everyday hard-floor cleaning **MAX Mode:** Designed for spot-cleaning stains and dried-on messes

Best Use Cases Hard-floor cleaning Wet spills Dried-on stains Kitchen messes Dust and dirt pickup Quick daily cleaning Low furniture cleaning Apartments and modern homes

Users who want a lightweight wet cleaner Users who want faster drying than traditional mopping

Compatibility Suitable for compatible hard floors Not designed for carpet cleaning Best used on sealed hard floors where wet cleaning is appropriate

Always check flooring care instructions before using wet cleaning appliances.

What's in the Box Dyson PencilWash Cordless Wet Cleaner × 1 Wand Charging Dock × 1 Cleaner Head × 1 Clip-On Drip Tray × 1